



Spare Parts No. and List

<MB 3315S>




Complete set : 3315S-1




No.	Name	No.	Name
3315S-1	Marking Head	COM-1-1	Pin Holder
COM-2-2	Head Cable Assy	COM-1-2	Solenoid Assy
3315S-3	Head Cover	COM-1-3	Solenoid Block
3315S-6	Marking Guide Window	COM-1-4	Stylus Pin
3315S-7	Shutter Kit	COM-1-6	Spring
3315S-9	Strap	COM-1-7	Hammer

*The above **bold section** is consumption articles. Please change them when you got some quality problems.

<MB 8020S>





Complete set:8020S-1



No.	Name	No.	Name
8020S-1	Marking Head	COM-1-1	Pin Holder
COM-2-2	Head Cable Assy	COM-1-2	Solenoid Assy
8020S-3	Head Cover	COM-1-3	Solenoid Block
8020S-6	Marking Guide Window	COM-1-4	Stylus Pin
8020S-7	Shutter Kit	COM-1-6	Spring
8020S-9	Strap	COM-1-7	Hammer

*The above **bold section** is consumption articles. Please change them when you got some quality problems.


<MB 1010>



No.	Name	No.	Name
1010-1	Marking Head	COM-1-1	Pin Holder
COM-2-2	Head Cable Assy	COM-1-2	Solenoid Assy
1010-3	Head Cover	COM-1-3	Solenoid Block
1010-4	SW Plate Assy	COM-1-4	Stylus Pin
1010-7	Shutter Kit	COM-1-6	Spring
COM-2-7	Stand	COM-1-7	Hammer

*The above **bold section** is consumption articles. Please change them when you got some quality problems.

<Big Solenoid>



No.	Name
BSD-1-3	BSD Solenoid Block
BSD-1-4-XXX	BSD Pin (XXX --- Angle)
BSD-1-6	BSD Spring
BSD-1-7	BSD Hammer
BSD-1-8	BSD Washer

*The above **bold section** is consumption articles. Please change them when you got some quality problems.