



[click here to watch.](#)

Direct Barcode Scan Data

This function allows you to insert the USB barcode reader directly into the MB3 controller and mark the data it reads. Unlike the Barcode Scan Marking in the previous chapter, a PC connection is not required.

- 1) Create the text field and send it to File1 from the "File Marking" on the menu bar.
- 2) Go to "Preferences" → "Settings" on the menu bar.
- 3) In the "Barcode reader" settings, check the "Direct barcode" and "Clear data off each marking" boxes.

Barcode reader

☒ Direct Barcode

Number of field

1

☒ Clear data off each marking

Barcode reader types

General

Number of fields	Scannable from 1 to 5 fields
Clear data off each marking	Check this box if you want to clear the marking data each time. If unchecked, the last barcode read data will be repeatedly marked.
Barcode reader types	Choose "General" usually. The barcode reader must be equipped with both the USB COM Port and USB HID (Keyboard) functions, and the USB HID mode must be turned on when used. Also, the Enter key barcode (CR, LF) must be enabled.

- 4) Scan barcode and start marking pressing the Start/Stop button on the marking head.

Contact

Please contact our distributor if you have an inquiry for operation and malfunction.

Manufacturer information:

Company : TOCHO MARKING SYSTEMS, Inc.

Address : 87-378 Yachimata-Ro, Yachimata, Chiba, Japan 289-1144

Tel : +81-43-308-4301

URL : <http://www.tokyo-chokoku.co.jp>