

## Patmark App Capabilities

• Including the PC, multiple devices cannot operate the Patmark simultaneously. Please begin operation without another device connected to the Patmark.

### 1 Single Line



Able to quickly mark a single line of text.

**Alphanumerics and symbols.**  
CHECK!

### 2 Read File



Able to read and mark any file saved in Patmark.

**After file is retrieved it can't be edited in the app.**  
CHECK!

### 3 Save Files



Able to save the marked file in a mobile device or Patmark

**The Patmark can save up to 255 files.**  
CHECK!



Please check out our **"Support"** page on the company website which has many helpful tutorial videos as well: Go to **"Support"** located at <https://www.tocho-america.com>

## 3 Quick Marking




Input text then tap **Next**




Select the model you wish to use.



Choose size, force and speed, then tap **Send** button to transmit data to the Patmark



Hold firmly with both hands, **press the start button**, and start marking.  
\* Pressing once will move the pin to the starting location, then pressing again will start marking.





**Individual settings for character size, force, and quality:**  
**Settings → Marking parameter** and adjust character size, force, and quality independently. Press Save to keep your settings.

## 4 File Operations



If the file name is not shown, select **Reload** and check for your file.




Tap the saved file name, then select the correct operation.

- ① Read file
- ② Save/Overwrite file
- ③ Change file name
- ④ Delete file



Tap the **Send** button after reading the file, and the information will be sent to the Patmark.  
\* To finish the Patmark file, please tap the **Clear** button.



**Saving Serial Numbers**  
When marking serial numbers and save the latest data, tap **read the latest marked data** first, and then save under **Patmark File**.

## 1 Patmark App Installation




Go to the "App Store" or "Google Play Store" and search for Patmark, then install the appropriate app. The following screen shots are taken from the iOS based app.




## 2 Connect to your Patmark via Wi-Fi

Turn on the power to the Patmark unit, then search for and connect via Wi-Fi from your phone.



When the **"Do you want to stay connected?"** message is displayed, select **"Yes."**



Please check that the **Wifi Mark** in the Patmark app is **green**. If the mark is **red**, tap the **WiFi mark** and check the communication between the devices.



\*\*\*\*\* is the Nameplate S/N displayed on the Patmark unit.

Patmark\*\*\*\*\*  
Find and connect

• For any questions about repairs or operations, please contact :  
**TOCHO MARKING SYSTEMS AMERICA, Inc.**  
Phone: +1-310-214-3367      Address: 4025 Spencer St. Suite 401, Torrance CA 90503  
WEB: <https://www.tocho-america.com>